





Load Calculations

- · Heating and Cooling
- · Accuracy important!
- Design conditions
- · Building shell load
- R, U value
- · Internal load
- · Ventilation load
- Infiltration
- · Occupancy schedules




000


Heat Transfer


- Conduction
- Convection
- Radiation
- Resistance (R-Value)
- U = 1 / R
- $G_{heat} = U \times A \times \Delta T$





U-Value is the rate of heat flow in Btu/h through a one ft² area when one side is 1°F warmer


























































Improved Ventilation Effectiveness

- Effective mixing of ventilation air within space
- Vary ventilation based on the number of occupants and process loads - changes in occupancy can be measured by CO₂ sensors
- Consider designs that separate ventilation and space conditioning
- Utilize heat recovery systems to reduce system size energy costs
- Avoid: loading docks, exhaust vents, plumbing stacks, waste collection & stagnant water



