

Types of loads:

Vertical loads

lateral - winds, earthquakes.

- A frame building has no bearing walls

Rafter

material used on roof. its at an angle used especial to roll down Rain fall.



- Moment force - a force that will make something rotate.
Created when ~~the~~ something is whelled together.