


Water Cement Ration - the amount of water needed to mix into the cement.

- Controls the strength, durability and hardness.
 - too much water makes the mix weak & porous.
 - too little water make the mix too dense, stiff.
- To test the Consistency & workability of fresh mixed concrete they do the **slump test**.



Steel Reinforcement - is used bc concrete is relatively weak in tension; Reinforcement consisting of steel bars, strands or wires

Reinforcing bars are steel sections hot-rolled with ribs or deformations



each bar size
has different
dimensions.