

Ribbon Cable Section

- The 16 wire **Ribbon Cable** that should be into three equal pieces (one is extra) one end of each piece should be crimped onto the wire clamp.
- You will need two strip two wires off from one of **Ribbon Cable** to fit in into the **1x14 Wire Clamp**. Once clamped the other end of each wire should be pulled apart and ends should be stripped, tinned and flagged.
- Note each **Ribbon Cable** originally has 16 cables linked together so to fit into the **1x14 Wire Clamp** you need to take two cables off from the 16 cables and to fit into the **1x16 Wire Clamp** no cutting on the **Ribbon Cable** is required

