


ARCH 2431
Building Technology III
Steel Assembly &
Building Information Modeling (BIM) with Revit



Steel Connections Series

- #1 Introduction to Columns & Beams
- #2 Column Base Plates
- #3 Photos & Videos Connections & Fasteners
- #4 Concrete footing to baseplate connection
- #5 Fin & Splice Plates Notched Beams
- #6 Diagonal Bracing


1.11

Building Technology III Prof. Paul C. King, Course Coordinator Prof. Blake Kurasek

Prof. Justin Sherman


Prof. Jieun Yang

Pking@CityTech.Cuny.Edu Bkurasek@CityTech.Cuny.Edu Jsherman@CityTech.Cuny.Edu Jyang@CityTech.Cuny.Edu




Building Technology III CityTech.CUNY.edu


Steel Connections Detail Development



- 22 X 34 Sheet
- <u>Coordinated Views</u> <u>& Isometrics</u>



- Base Plate & Footing
- Fin Plate Connection
- Splice Plate Connection
- Notched Beam with Bolting Plate



Isolated Footing

- Concrete Extrusions
- Cone Shaped Void
- Components
- Threaded Rod
- Nut & Washer
- Concrete

Footing Family

- Add Threaded Rod
- Add Nut
- Add Washers
- Position & Copy
- Steel

Connections

Project File

- Align & Lock Footings to the Columns
- Concrete

Footing Family

- Add Threaded Rod
- Add Level 1 Floor Slab
- Create Section Views &


Develop Details

- Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet


Building Technology III

CityTech.CUNY.edu

Concrete Footing to Baseplate Connection



Watch the Video



Column Base Plate to Isolate Footing

Lecture Title

Connections

Video & sample

Isolated Footin

• Concrete Extrusions

Cone Shaped Void

Components

■ Threaded Rod

Nut & Washer

Concrete

Footing Family

- Add Threaded Rod
- Add Nut
- Add Washers
- Position & Copy
- Steel

Connections

Project File

- Align & Lock Footings to the Columns
- Concrete

Footing Family

- Add Level 1 Floor Slab


Develop Details

- Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet


Building Technology III


CityTech.CUNY.edu


Create Concrete Isolated Footing





• Create > Extrusion (base of footing Start -4', End -5')











Connections

Isolated Footi

Components

- Threaded Rod
- Nut & Washer
- Concrete

Footing Family

- Add Threaded Rod
- Add Nut
- Add Washers
- Position & Copy
- Steel

Connections

Project File

- Align & Lock Footings to the Columns
- Concrete


Footing Family


- Add Level 1 Floor Slab
- Develop Details
 - Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet

Building Technology III


CityTech.CUNY.edu


Concrete Isolated Footing with recess for Hold Down Bolts




















Create Cone Shaped Void

- Create 4 Reference Planes & Lock at 4"
- Create > Void Blend
 - Top ¾" Radius
 - Base 3/8" Radius
 - First End 0'-0"
 - Second End -7 1/2"

Lecture Title

- Connections
- Video & sample

Isolated Footing

- Concrete Extrusions
- Cone Shaped Vo

Components

- Threaded Ro
- Nut & Washer
- Hut & Washe
- Concrete
 Footing Family
 - Add Threaded Rod
 - Add Nut
 - Add Washers
 - Position & Copy
- Steel
 - Connections

Project File

- Align & Lock Footings to the Columns
- Concrete


Footing Family


- Add Level 1 Floor Slab
- Develop Details
 - Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet


Building Technology III

Create Threaded Rod, Nut & Washers (import)

- Hold-Down Bolt is made of a threaded rod, nut and washers
- Create > Extrusion (1' rod)
- Transfer Project Standards
- (Copy from your project file)
- Import Materials Library
- Select "Rod" and set Material Category
- Steel ASTM A992







 For all families get in the habit of assigning materials so they render and detail correctly

- Concrete **Footing Family**
 - Add Threaded Rod
 - Add Nut
 - Add Washers
- Position & Copy
- Steel
- Connections

Project File

- Align & Lock Footings to the Columns
- Concrete

Footing Family


- Add Level 1 Floor Slab
- Develop Details
- Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet


Building Technology III

CityTech.CUNY.edu


Create Threaded Rod, Nut & Washers (import)


- Because you need more than one of each component, create each in a separate family file then combine these in the concrete footing family
- Steel Nut






- Steel Washer
- ½" radius with ¼" radius hole x 3/8" high ¾" radius with 5/16" radius hole x 1/8" high











- Steel
- **Connections**

Project File

- Align & Lock Footings to the Columns
- Concrete

Footing Family


- Add Level 1 Floor Slab
- Develop Details
- Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet

Building Technology III


CityTech.CUNY.edu


Assemble Components in Concrete Footing Family

· Load the Threaded Rod, Nut & Washer into the Concrete Footing Family



- Locate each component and make certain each is locked to the correct reference planes
- Set the material for the footing to concrete, cast -in-place
- Load the Footing Family into the project file.
- All sub families will load as well





Cone

Shaped

Void



Washer

Nut

- Concrete


Footing Family


- Add Level 1 Floor Slab
- Develop Details
 - Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet

Building Technology III

CityTech.CUNY.edu

Align & Lock the Concrete Footing to the Column





- Base plate of column must be raised 2" to allow for shims and grout
- Column must be 2" shorter (from 15'-0" down to 14'-10")

- Connections

Component


Develop Details

- Create Section Views
- Provide a good name
- Add Notes & Leaders
- Add Dimensions
- Add to your sheet

Building Technology III

CityTech.CUNY.edu

Add a Concrete Floor Slab on Level 1 Structural




· Create a Structural Floor • Select Generic 12"


Concrete Slab 8 inch

• Structure > Thickness = 8" • Material = Concrete

• Duplicate >

- Coarse Scale Fill Pattern Coarse Scale Fill Color Black
- Duplicate... 0.700000
- 15.0210 BTU/F Thickness = 8" Material = Concrete
- Draw Rectangle at each footing Snap & Lock to the concrete
 - Draw Rectangle with 6' offset from grid intersection to grid intersection
 - (use space to flip offset direction)
 - Add Rectangle at each footing snap & lock to the concrete not the steel







Building Technology III

CityTech.CUNY.edu


Modify Base Plate Elevations as needed – add details





- Develop a detail of the footing condition
- Note the 2" distance from top of plate to concrete
- Top of Footing can also be recessed to allow for finish flooring to cover





Building Technology III

CityTech.CUNY.edu

Isometric views of Completed Column & Isolated Footings

