



Top View Flat G,H

Notes:

1

$\frac{3}{4}$ " Ply Wood for Framing Members

Apply Lauan Facecover for framing lid.

For insertion of pickpoints, use a  $\frac{3}{16}$ " drillbit.

Use foam core board for crown moulding.

For kerf bending plywood, cut the plywood about  $\frac{1}{2}$ " to  $\frac{5}{16}$ " from the actual thickness. Once doing so, fill the gaps with glue and sawdust once finished.

If making an angled cut for the stiles and rails, use a angled cut jig with a jig saw tool.

<b>NYC COLLEGE OF TECHNOLOGY</b>	
<b>ENT 4410 - Technical Direction</b>	
<b>Problem 3 Flat G,H</b>	PLATE NO.
DRAWING PRACTICE WORKSHEET	
SCALE:	1/2" = 1'-0"
DATE:	April 13th, 2023
DRAFTER:	Tristen Weber
	<b>1</b>
	OF: 1