

How to Program Your Cablevision/IO remote to your T.V.



Below are instructions on how you can program you Cablevision/IO remote controller to your T.V.

Pre-Programming:

Before anything you need to make sure your Cablevision/IO remote is equipped with two AA Alkaline batteries as shown below:



Once you have installed the batteries into the remote you are ready to go.

Programming The Cablevision/IO Remote Control

Step 1: Turn on the Television you wish to program



Note: Does not need to be set to your favorite channel

Step 2: Hold your remote face up. Now locate the “TV” and “Select” buttons. Once you have located them, press down on the buttons at the same time (simultaneously).



Once done you should see the IO button turn on with a red to indicate the remote is ready to be programmed to your T.V.



Step 3: Now point the Cablevision/IO remote to the destined T.V. you are programming and enter the three digit code you will need that is assigned to brand of T.V. *List below the three digit codes in order to program below.*



Above is the list that contains the three digit codes in order to program your T.V. You can also find the codes on the web when you visit www.universalremote.com

Note: The red light will blink off and then on once the correct code is entered the T.V. will shut off automatically.

Step 4: Once you see your T.V. has been shutoff you will be able to store the three digit code by pressing down on the “TV” button.



The IO button will blink twice when the remote has saved the three digit code to confirm

Step 5: Now you are ready to test your remote and your T.V. Try all the functions on the remote to confirm everything works. *If any case the remote did not get programmed repeat the steps above and try again.*