




# Glass Curtain Walls And Opaque Facades


Eduardo Ramirez Kayla Staton, Tenly Law, Jean-Paul

### ROBERT D. MORETON BUILDING










#### Terracotta (TerraClad)

Ceramic panels installed on an aluminum framing system offer the durability of a masonry installation without the weight

The system is mortar-less so it allows for installation in any weather conditions which reduces maintenance costs


Replacement of a panel does not require the entire stacked bond to be removed

Pre-punched system speeds installation




**Cladding Methods** 


Horizontal Track




Vertical Track



## Insulation



11



Simple to Install

Peter

FACE BRICK

IDACK ID

Prepare site and install track



Install TerraClad™ panels



Continue building TerraClad™ courses


Replacing a panel is easy

#### https://vimeo.com/5195114

#### Details

Inside Corner Details - Vertical Track

#### **Outside Corner Details - Vertical Track**



FLANGED END TRACK, 3/8" OPEN JOINT

Plan Detail

FLANGED END TRACK, 3/8" QUIRK MITERED CORNER

2 1/2\*- 3\*---

#### Methodist Stone Oak Hospital

San Antonio, Texas, USA






#### 2250 IG (Inside Glazed) Curtain Wall System







TYPICAL ELEVATION ELEVATION SCALE: 1/8" = 1'-0"







TYPICAL ELEVATION









90° OUTSIDE CORNER SCREW SPLINE




90° OUTSIDE CORNER SHEAR BLOCK




SCREW SPLINE




90° INSIDE CORNER SHEAR BLOCK











#### Resources

https://www.bostonvalley.com/downloads/BVTC.install-guide.Panels.FINAL\_SCREEN.pdf

https://bostonvalley.com/wp-content/uploads/2015/03/2015.03-Terraclad-Marketing-Catalog.pdf

https://bostonvalley.com/downloads/BVTC.TerraClad\_book-web.pdf

<u>https://www.kawneer.com/kawneer/north\_america/en/product.asp?prod\_id=1808&desc=inside-glazed-curtain-wall-syst</u> <u>em</u>

<u>https://www.kawneer.com/kawneer/north\_america/en/products/project\_detail.asp?project=methodist\_stone\_hospital&b</u> <u>us=north\_america&pc=Healthcare</u>

https://www.kawneer.com/kawneer/north\_america/catalog/97911/ADMD150EN.pdf